



🌐 WWW.BAESIQRENTALS.COM ✉ BAESIQRENTALS@GMAIL.COM

☎ 876- 525-2900 📷 📺 📺 BAESIQRENTALS

POP UP TENT

Thank you for choosing to rent a pop-up tent from Baesiq Rentals! Please follow these step-by-step instructions to ensure proper and safe use of the tent.

Set-Up Instructions

1. Unpack and Lay Out-Open the carrying bag and carefully remove the tent frame and canopy. Lay the frame on the ground where you plan to set it up.
2. Extend the Frame -Stand on the opposite sides of the frame (two people required for safety and ease). Grab the frame and slowly begin pulling it apart to extend the legs. Ensure the frame is even on both sides as you extend.
3. Raise the Tent -Continue pulling the frame upward until it's fully extended. Each leg should be fully extended before moving to the next step.
4. Lock the legs in place: Secure each leg at the desired height by locking the pins or adjusting the locks on the legs. Most pop-up tents have adjustable legs to control the height.

1. Attach the Canopy - Once the frame is standing, drape the canopy over the top of the frame. Ensure the corners of the canopy are aligned with the frame.
2. Secure the canopy to the frame using the provided velcro straps or clips. Make sure the canopy is evenly distributed and fits snugly on all sides.
3. Secure the Tent- Use the provided stakes and guy ropes to secure the tent to the ground. This is especially important in windy conditions to prevent the tent from tipping over. If applicable, add weights to the corners of the tent to ensure stability.
4. Using the Tent -Do not overload: Avoid placing excessive weight on the tent or hanging heavy objects from the frame to prevent damage.

In strong winds or heavy rain, it's advised to disassemble the tent to avoid damage.

Take-Down Instructions

1. Remove the stakes and any weights from the corners of the tent. Ensure that no sharp objects remain on the ground that could damage the tent fabric.
2. Carefully unclip or un-velcro the canopy from the frame and gently fold it. Avoid dragging or pulling the canopy too hard to prevent tearing.
3. Begin folding the frame by reversing the setup process. Start by lowering one leg at a time to collapse the frame. You may need to press a button or pull a pin to allow the frame to collapse.

Once the frame is collapsed, fold the canopy and neatly place it back into the carrying bag along with the frame.

Ensure all parts (frame, canopy, stakes, and ropes) are packed back into the bag for easy transport and to avoid losing any components.

Important Notes

- Always check stability: Ensure the tent is stable and secure during use. If necessary, adjust the height or tighten the guy ropes and stakes.
- Always be cautious of weather conditions, especially if the tent is outdoors for an extended period. Strong winds can easily damage the tent if it is not properly secured.
- Be careful not to force any parts of the tent, as this can lead to breakage. Always follow the steps slowly and carefully.
- Before folding and packing the tent, ensure that any debris such as leaves, dirt, sand, or other materials are removed from both the frame and canopy
- Ensure the tent is completely dry before packing it away. Moisture can lead to mildew or mold buildup, which may damage the fabric. If the tent has gotten wet during use, set it up again in a dry area or allow it to air dry thoroughly before folding it.
- Do not place open flames under tent